

NÁVOD / INSTRUCTION

Promo table Ambient



1. After you affix the theme cut off 3cm of the top and 3cm of the bottom. Do sides and front separately, not in one piece.



2. Insert the branded board into the lower shelf.



3. Put the upper shelf in place.




4. Secure the board with fastening hitch that is placed in the upper and lower part of the shelf.




5. Insert middle shelf.




6. Fit the middle shelf into hitches that are ready on the inner side of the board.



7. Connect poles for the topper.



8. Insert pole into the upper part of the shelf.



9. Place the topper on the upper part of the pole.

If you don't follow instructions in this manual, we will not acknowledge any potential complaints.